

SWAROVSKI ELEMENTS

TABLE OF SIZES

• PP 1 (SS 000) 0.80–0.90 mm	• PP 21 (SS 10) 2.70–2.80 mm	• SS 25 5.44–5.61 mm	• SS 45 9.85– 10.19 mm
• PP 2 (SS 00) 0.90–1.00 mm	• PP 22 (SS 10) 2.80–2.90 mm	• SS 26 5.61–5.78 mm	
• PP 3 (SS 0) 1.00–1.10 mm	• PP 23 (SS 11) 2.90–3.00 mm	• SS 27 5.78–5.96 mm	• SS 46 10.19– 10.54 mm
• PP 4 (SS 1) 1.10–1.20 mm	• PP 24 (SS 12) 3.00–3.20 mm	• SS 28 5.96–6.14 mm	
• PP 5 (SS 2) 1.20–1.30 mm	• PP 25 (SS 13) 3.20–3.30 mm	• SS 29 6.14–6.32 mm	• SS 47 10.54– 10.91 mm
• PP 6 (SS 2) 1.30–1.35 mm	• PP 26 (SS 13) 3.30–3.40 mm	• SS 30 6.32–6.50 mm	
• PP 7 (SS 3) 1.35–1.40 mm	• PP 27 (SS 14) 3.40–3.50 mm	• SS 31 6.50–6.68 mm	• SS 48 10.91– 11.30 mm
• PP 8 (SS 3) 1.40–1.50 mm	• PP 28 (SS 14) 3.50–3.60 mm	• SS 32 6.68–6.87 mm	
• PP 9 (SS 4) 1.50–1.60 mm	• PP 29 (SS 15) 3.60–3.70 mm	• SS 33 6.87–7.07 mm	• SS 49 11.30– 11.72 mm
• PP 10 (SS 4) 1.60–1.70 mm	• PP 30 (SS 15) 3.70–3.80 mm	• SS 34 7.07–7.27 mm	
• PP 11 (SS 5) 1.70–1.80 mm	• PP 31 (SS 16) 3.80–4.00 mm	• SS 35 7.27–7.48 mm	• SS 50 11.72– 11.97 mm
• PP 12 (SS 5) 1.80–1.90 mm	• PP 32 (SS 17) 4.00–4.10 mm	• SS 36 7.48–7.70 mm	
• PP 13 (SS 6) 1.90–2.00 mm	• PP 33 (SS 17) 4.10–4.20 mm	• SS 37 7.70–7.93 mm	• SS 55 12.97– 13.22 mm
• PP 14 (SS 6) 2.00–2.10 mm	• SS 18 4.20–4.40 mm	• SS 38 7.93–8.16 mm	
• PP 15 (SS 7) 2.10–2.20 mm	• SS 19 4.40–4.60 mm	• SS 39 8.16–8.41 mm	• SS 60 14.22– 14.47 mm
• PP 16 (SS 7) 2.20–2.30 mm	• SS 20 4.60–4.80 mm	• SS 40 8.41–8.67 mm	
• PP 17 (SS 8) 2.30–2.40 mm	• SS 21 4.80–4.90 mm	• SS 41 8.67–8.95 mm	• SS 65 15.47– 15.72 mm
• PP 18 (SS 8) 2.40–2.50 mm	• SS 22 4.90–5.10 mm	• SS 42 8.95–9.23 mm	
• PP 19 (SS 9) 2.50–2.60 mm	• SS 23 5.10–5.27 mm	• SS 43 9.23–9.53 mm	• SS 70 16.72– 16.97 mm
• PP 20 (SS 9) 2.60–2.70 mm	• SS 24 5.27–5.44 mm	• SS 44 9.53–9.85 mm	• SS 75 17.97– 18.22 mm